

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	<input checked="" type="checkbox"/>
LAND OFFICE	<input checked="" type="checkbox"/>
OPERATOR	<input checked="" type="checkbox"/>

NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED BY

NOV 01 1984

O. C. D.  
ARTESIA OFFICE

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease

State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☐ GAS WELL ☐ OTHER- Dry Hole

2. Name of Operator  
McClellan Oil Corporation

3. Address of Operator  
P.O. Drawer 730, Roswell, New Mexico 88202

4. Location of Well  
UNIT LETTER J, 2020.7 FEET FROM THE South LINE AND 2010.2 FEET FROM  
THE East LINE, SECTION 6 TOWNSHIP 5-S RANGE 27-E NMPM.

7. Unit Agreement Name

8. Farm or Lease Name

Van "A" Fee

9. Well No.

1

10. Field and Pool, or Wildcat

Undesignated Abo

15. Elevation (Show whether DF, RT, GR, etc.)

4008' G.L.

12. County

Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐

OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER Stimulation ☒

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

10-22 Perfed 1929-1935', 2104-07', 2175-78'. Acidized w/ 2500 gals 20% HCL acid. Swabbed tested. No show.

10-26 Set CIBP at 1810. Perfed 1596-1602'. Acidized w/ 1000 gals 15% NE acid. Swabbed tested. No show.

10-30 Propose to PTA as per Larry Brooks:  
Set 100' cement plug across ~~1596-1602~~. 1546-1646  
Set 100' cement plug from ~~1225-1325~~. 1457-1357 & 980-880  
Set 15 sack plug at surface.  
Install dry hole marker. Clean and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Paul Reynolds TITLE Operations Manager

DATE 10/31/84

APPROVED BY ORIGINAL SIGNED BY LARRY BROOKS  
GEOLOGIST - NMOC

TITLE

DATE DEC 28 1984

CONDITIONS OF APPROVAL, IF ANY:

100-443860  
100-443861  
100-443862