

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPL
(Other instructions on re-
verse side)

Form approved by
Budget Bureau No. 1004-0135
Expires August 31, 1985

clsf

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR STEVENS OPERATING CORPORATION	8. FARM OR LEASE NAME Melvin Fed. Com.
3. ADDRESS OF OPERATOR P.O. BOX 2203, ROSWELL, NM. 88201	9. WELL NO. #1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1980 FNL, 1980 FWL	10. FIELD AND POOL, OR WILDCAT West Pecos Slope Abo
11. SEC. T. R. M., OR BLK. AND SURVEY OR AREA Sec. 29, T6S, R23E	12. COUNTY OR PARISH Chaves
13. STATE NM	
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, FT, GR, etc.) 4059 GR

RECEIVED BY
DEC -9 1985
O. C. D.
ARTESIA, OFFICE

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF	☐	PULL OR ALTER CASING	☐
FRACTURE TREAT	☐	MULTIPLE COMPLETE	☐
SHOOT OR ACIDIZE	☐	ABANDON*	☒
REPAIR WELL	☐	CHANGE PLANE	☐
(Other)	☐		

WATER SHUT-OFF	☐	REPAIRING WELL	☐
FRACTURE TREATMENT	☐	ALTERING CASING	☐
SHOOTING OR ACIDIZING	☐	ABANDONMENT*	☐
(Other)	☐		

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

8 5/8" Surf. csg. @ 1005' cement circ. 4 1/2" Production csg. @ 3494'.
Approximate TOC @ 1005'. ABO Perforations: 2872'-2924'.

P & A Proposal-

1. Set CIBP @ 2823' w/ 35' cement cap T.O.C.
2. Set Wire Line B.P. @ 2257' w/ 35' cement cap T.O.C.
3. Run Free Point to find cement top.
- * 4. Set Wire Line BP @ ~~500'~~ w/ 35' cement cap T.O.C.
5. Set 50' cement plug @ surf. 1000'
6. Set Dry Hole marker.

BWC

* If TOC is not to at least 900' in 4 1/2"-8 5/8" annulus, you will need to squeeze cement in annulus from at least 1055' to 900'. BWC.

18. I hereby certify that the foregoing is true and correct

SIGNED *[Signature]*
(This space for Federal or State office use)

TITLE Production Manager

DATE November 25, 1985

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED
PETER W. CHESTER

DEC 6 1985

BUREAU OF LAND MANAGEMENT
ROSWELL RESOURCE AREA

*See Instructions on Reverse Side