



NEW MEXICO ENERGY, MINERALS and NATURAL RESOURCES DEPARTMENT

GARY E. JOHNSON
Governor
Jennifer A. Salisbury
Cabinet Secretary

Lori Wrotenberg
Director
Oil Conservation Division

11/27/01

copy

Jack J. Grynberg
Prentice Point, Suite 500
5299 DTC Boulevard
Greenwood Village, Co. 80111-332

RE: HORSE CREEK ST. COM. # 2
GRYNBERG 32 ST. # 3
GRYNBURG 16 ST. # 3
GRYNBURG 16 ST. # 4

C-4-5-24	30-005-61935
N-32-5-24	30-005-61344
E-16-5-24	30-005-61151
G-16-5-24	30-005-61152

Dear Sirs:

An inspection of your wells on 11-01-2001 found these wells not producing. A search of the records found no production for the last year. The wells have been idle for 12 months which puts them in violation of Rule 201.B. These wells must be brought into compliance on or before 27 February, 2002. To bring them into compliance you have 3 options:

1. Put the wells into production.
2. T.A. the wells.
3. P. A. the wells.

Thank you for your prompt attention to this matter and your efforts in helping to protect our environment and the infrastructure of the oil and gas industry.

Sincerely,

Van Barton
Field Rep. II

30.015-61154

1980 N/660'W-16.5.24

Jack J. Grynberg

Grynberg State 16 #3

After

1. Run & set CIBP @ 3466' w/35' cement.
or Run tubing to 3466'.

Set 25 sx cement Plug 3466'-3366'. TAG

2. Circulate brine gel.

3. Set 25 sx cement Plug @ 1160'.

4. Perforate 4 1/2" casing @ 975'.

5. Run Packer, Squeeze cement 100' cement Plug.
inside & outside 4 1/2" casing. TAG

6. Perforate 4 1/2" @ 100'
Circulate cement to surface
inside & outside 4 1/2" casing.

7. Cut & level all surface pits.
cut deadmen, clear location of junk.
Erect dry hole marker.

10 3/4" csg
set @ 925'

4 1/2" csg

set @ 3900'

w/1100

Toc - 925'

= Perfs 3566'-83'

No Flowline
No Well Sign.
Shot- IN.

11/01/01

RJ