

UNITED STATES OF AMERICA
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 15857

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Amoco Depco Federal

9. WELL NO.

#1

10. FIELD AND POOL, OR WILDCAT

Undes. Abo.

11. SEC., T., R., M., OR BLK. AND

SURVEY OR AREA

Sec. 31, T7S, R24E

12. COUNTY OR PARISH

Chaves

13. STATE

N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

PETROLEUM DEVELOPMENT CORPORATION

3. ADDRESS OF OPERATOR

9720-B Candelaria, N.E., Albuquerque, New Mexico, 87115

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)

At surface

1,980' FNL, 1,980' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3,674' GL/3,686' K.B.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

T.D. 3815'

Perf. 4 1/2", 10.5# casing @ 3,384'-3,484'. Produced salt water.

CIBP set @ 3,350' & 25' of cement on top.

Perf. 4 1/2", 10.5# casing @ 3,260'-3,280' - produced salt water.

Approx. 8/1/82:

1. Set CIBP @ 3,200'. Dump 35' cement on CIBP

2. Set 10 sack plug: 3,070' - 2,900'.

3. Set 10 sack plug: 1,000' - 870'.

4. Set 5 sack plug: at surface.

5. Install dry-hole marker.

RECEIVED
JUL 15 1982

OIL & GAS
U.S. GEOLOGICAL SURVEY
ROSWELL, NEW MEXICO

P. W. Chester

18. I hereby certify that the foregoing is true and correct

SIGNED

Gary L. Roberts

TITLE

Field Manager

DATE

7/12/82

(This space for Federal or State Office Use)

APPROVED

(Signature) PETER W. CHESTER

TITLE

DATE

CONDITIONS OF APPROVAL IN ANY

JUL 16 1982

JAMES A. GILLHAM
DISTRICT SUPERVISOR

*See Instructions on Reverse Side