

+ c15F  
0P

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240  
  
DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210  
  
DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

RECEIVED  
SEP 28 1992

O. C. D.

WELL API NO. 30-005-61378
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name  Western Com
8. Well No. 1
9. Pool name or Wildcat Pecos Slope Abo
10. Elevation (Show whether DF, RKB, RT, GR, etc.)

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER P&A
2. Name of Operator YATES PETROLEUM CORPORATION
3. Address of Operator 105 South 4th St., Artesia, NM 88210
4. Well Location Unit Letter M : 660 Feet From The South Line and 660 Feet From The West Line Section 19 Township 6S Range 25E NMPM Chaves County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well as follows:

- \* 1. Set CIBP at 3350' and cap w/35' cement.
- 2. Circulate hole with mud laden fluid.
- 3. Spot 25 sack plug @ 2680-2780'.
- \* 4. Spot 25 sack plug @ 1700-1800'.
- \* 5. Spot 25 sack plug @ 850-950'.
- 6. Spot 10 sack plug @ surface.
- 7. Install dry hole marker.
- 8. Clean and abandon location.

Set CIBP 3363 35' cement  
1700-1800 CEMENT inside + outside 4 1/2 - Tag  
850-950 CEMENT inside + outside 4 1/2 - Tag

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Juanita Goodlett TITLE Production Supervisor DATE 9-24-92

TYPE OR PRINT NAME Juanita Goodlett TELEPHONE NO. 505/748-1471

(This space for State Use) \* AS NOTED ABOVE

APPROVED BY [Signature] DATE 10/1/92

CONDITIONS OF APPROVAL, IF ANY: