

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
811 South First, Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised March 25, 1999

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL/API NO.  
30-005-61395

5. Indicate Type of Lease  
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name:  
Acme Com

8. Well No.  
12

9. Pool name or Wildcat  
Pecos Slope Abo

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH  
PROPOSALS.)

1. Type of Well:  
Oil Well ☐ Gas Well ☒ Other

2. Name of Operator  
Yates Petroleum Corporation

3. Address of Operator  
105 So. 4th St. - Artesia, NM 88210

4. Well Location  
Unit Letter 0 : 660 feet from the South line and 1980 feet from the East line  
Section 20 Township 8S Range 26E NMPM Chaves County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)  
3732' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/> MULTIPLE COMPLETION <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER: <input type="checkbox"/>	OTHER: <input type="checkbox"/>

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Propose to plug and abandon as follows:

1. RIH and tag CIBP set at 4300'. Circulate hole with plugging mud. Spot a 25 sack Class C Neat cement plug on top of CIBP at 4300'.
2. Spot a 35 sack Class C Neat cement plug at 2100'.
3. Perforate at 975' and squeeze with 100 sacks Class C Neat cement. WOC. Tag plug.
4. Perforate 4-1/2" casing at 60'. Circulate cement to surface inside and out.
5. Install regulation abandonment marker.

NOTIFY OCD-ARTESIA (505-748-1283) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS

NOTE: Approval to plug was obtained by Roger Brooks with BCM & Associates.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Agent for BCM & Associates DATE June 11, 2002

Type or print name Rusty Klein Telephone No. 746-6565

(This space for State use)

APPROVED BY [Signature] TITLE Wild Sep ID DATE JUN 12 2002

Conditions of approval, if any: