

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED

MAR 19 1982

O. C. D.
ARTESIA OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.		

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator McClellan Oil Corporation /	8. Farm or Lease Name Fahrlender Fee
3. Address of Operator P.O. Drawer 730, Roswell, New Mexico 88202	9. Well No. 1
4. Location of Well UNIT LETTER F, 1980 FEET FROM THE North LINE AND 1980 FEET FROM West LINE, SECTION 13 TOWNSHIP 6S RANGE 27E NMPM.	10. Field and Pool, or Wildcat Wildcat Also
15. Elevation (Show whether DF, RT, GR, etc.) 4026' G.L.	12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

3/18/82: Drilled to 5200' with 7-7/8" bit. Logs show well to be unproductive.

Propose to plug and abandon as follows:

Log Tops

- | | |
|---|------------------|
| 1. Set a 100 foot plug from 5100'-5200'. | Glorieta - 2557' |
| 2. Set a 100 foot plug from 4650'-4750'. | Tubb - 3980' |
| 3. Set a 100 foot plug from 3930'-4030'. | Abo - 4698' |
| 4. Set a 100 foot plug from 2500'-2600'. | 8-5/8" at 1400' |
| 5. Set a 100 foot plug from 1350'-1450' and tag plug. | |
| 6. Set a 15 sack plug at surface and install dry hole marker. | |

Minimum plug will be 25 sacks except at surface.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Paul Raygole TITLE Operations Manager DATE March 18, 1982

APPROVED BY Mike Wilbur TITLE OIL AND GAS INSPECTOR DATE MAR 22 1982

CONDITIONS OF APPROVAL, IF ANY: