

Submit 3 Copies
to Appropriate
District Office
DISTRICT I

1625 N. French Dr., Hobbs, NM 88240

DISTRICT II
811 S. First Street, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

State of New Mexico
Energy, Minerals Natural Resources Department

OIL CONSERVATION DIVISION

1220 South St. Francis Dr.
Santa Fe, New Mexico 87505

C. S. [Signature]

Form C-103
Revised 1-1-89

WELL API NO. 30-005-62340
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name O'Brien
8. Well No. #1
9. Pool Name or Wildcat Miller Lake Abo

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☐ GAS WELL ☒ OTHER

Name of Operator
STRATA PRODUCTION COMPANY

3. Address of Operator
P.O. BOX 1030, ROSWELL, NEW MEXICO 88202-1030

4. Well Location
Unit Letter **C** : **660'** Feet From The **North** Line and **1900'** Feet From The **West** Line

Section **25** Township **7S** Range **29E** NMPM **Chaves** County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
4104'

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work)
SEE RULE 1103

25 sx plug @ 5780'

Set CIBP @ 6425', with 35' cement. Circulate hole with 9# mud. Cut and pull casing @ +/- 5300'.
Spot 100' plug, 25 sx half in and half out of casing stub, tag plug. Spot 100' plug, 25 sx, 3550' - 3450'. Spot 100' plug, 25 sx, 2278' - 2378', tag plug. *100' plug 1183' - 7282' - 749* Spot 100' plug, 25 sx, 877' - 977'. Spot 100' plug 25 sx, 288' - 388'. Spot 60', 15 sx surface plug. Install dryhole marker, clean location and rip.

(Attachment: Plugging Procedure)

Notify OCD 24 hrs. prior to any work done

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Kelly M. Britt* TITLE PRODUCTION RECORDS DATE March 14, 2002

TYPE OR PRINT NAME Kelly M. Britt TELEPHONE NO. 505-622-1127

(This space for State Use)

APPROVED BY *[Signature]* TITLE *Wild Sep 10* DATE APR 3 2002

CONDITIONS OF APPROVAL: ANY