

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 88210
District III
1000 Rio Bravo Rd., Aztec, NM 87410
District IV
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-005-62635
1. Type of Well: Oil Well ☐ Gas Well ☐ Other ☐		5. Indicate Type of Lease STATE ☐ FEE ☒
2. Name of Operator Jalapeno Corporation		6. State Oil & Gas Lease No.
3. Address of Operator P. O. Box 1608 Albuquerque, New Mexico 87103-1608		7. Lease Name or Unit Agreement Name: LE 6
4. Well Location Unit Letter O 330 feet from the South line and 2310 feet from the East line Section 6 Township 10S Range 28E NMPM Chaves County		8. Well No. 1
10. Elevation (Show whether DR, RKB, RT, GR, etc.) 3824.5 GR.		9. Pool name or Wildcat Raostrack San Andres

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐ OTHER: ☐	SUBSEQUENT REPORT OF: REMEDIAL WORK ☐ ALTERING CASING ☐ COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐ CASING TEST AND CEMENT JOB ☐ OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

- * 25SX CEMENT Plug 2192'-2087' or CFBP w/35' cement.
- 1) Set 25 sack plug from 1615' to 1695' to cover top of San Andres and tag.
 - 2) Fill hole with mud and cut casing.
 - 3) Set 35 sack plug across casing stub and tag. 50' in 50' OUT.
 - 4) Set 35 sack plug from 1000' to 1100' to cover top of Queen.
 - 5) Set 35 sack plug from 215' to 315' to cover base of surface casing. TAG
 - 6) Set ten sack plug at surface and set dry hole marker.



* Notify NMOC to witness Plugging Operations.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE J. A. Gustamantes TITLE Production Supervisor DATE Feb 7 2000

Type or print name J. A. Gustamantes
(This space for State use)

Telephone No. 505-347-2375

APPROVED BY Mike Stubbfield TITLE Field Rep. II DATE 2/8/2000
Conditions of approval, if any: