

FIELD REPORT FOR CEMENTING OF WELLS

OIL CONSERVATION DIVISION

Operator <u>Gates Petr Corp</u>		Lease <u>Geneva UI Com</u>		Well # <u>1</u>	
Location of Well	Unit <u>C</u>	Section <u>20</u>	Township <u>6</u>	Range <u>25</u>	County <u>Chaves</u>
Drilling Contractor	<u>Und.</u>		Type of Equipment <u>Rotary</u>		
* Witness <u>APPROVED CASING PROGRAM</u>					
Size of Hole	Size of Casing	Weight Per Foot	New or Used	Depth	Sacks Cement
<u>17 1/2"</u>	<u>13 3/8"</u>	<u>54.5</u>		<u>650'</u>	<u>circ.</u>
<u>12 1/4"</u>	<u>8 5/8"</u>	<u>24 #</u>		<u>1500'</u>	<u>circ.</u>
<u>7 7/8"</u>	<u>4 1/2"</u>	<u>9.5 #</u>		<u>TD</u>	<u>350 rx</u>
Casing Data:					
Surface _____ joints of _____ inch _____ # Grade _____ (Approved) (Rejected) _____					
Inspected by _____ date _____					
Cementing Program					
Size of hole <u>17 1/2"</u> Size of Casing <u>13 3/8"</u> Sacks cement required _____					
Type of Shoe used <u>guide</u> Float collar used <u>insert</u> Btm 3 jts welded <u>yes</u>					
TD of hole <u>650'</u> Set <u>650'</u> Feet of <u>13 3/8"</u> Inch <u>54.5</u> # Grade <u>J-55</u>					
New used csg. @ <u>650'</u> with <u>200 2% cc</u> sacks neat cement around shoe					
+ <u>100</u> sack <u>thirset</u> additives <u>2% cc, 10" gilsonite, 1/2" floreal</u>					
Plug down @ <u>4:45</u> (AM) (PM) <u>PM</u> Date <u>6-12-89</u>					
Cement circulated <u>yes</u> No. of Sacks <u>100</u>					
Cemented by <u>Western Co.</u> Witnessed by <u>Mike Stubblefield</u>					
Temp. Survey ran @ _____ (AM) (PM) Date _____ top cement @ _____					
Casing test @ _____ (AM) (PM) Date _____					
Method Used _____ Witnessed by _____					
Checked for shut off @ _____ (AM) (PM) Date _____					
Method used _____ Witnessed by _____					
Remarks: <u>+ 350 rx Hall. Lite 1/4" floreal, 3% cc</u>					
Last dry break @ <u>480'</u>					