

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

CIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

RECEIVED

SEP 30 1991

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No. N/A	

O. C. D.  
ARTESIA OFFICE

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT DEPTH OR TO USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator PRIMERO OPERATING INC. ✓		8. Farm or Lease Name Plains "22"
3. Address of Operator PO BOX 1433, ROSWELL, NM 88202-1433		9. Well No. 1
4. Location of Well UNIT LETTER <u>G</u> <u>2310</u> FEET FROM THE <u>North</u> LINE AND <u>2310</u> FEET FROM THE <u>East</u> LINE, SECTION <u>22</u> TOWNSHIP <u>10S</u> RANGE <u>27E</u> NMPM.		10. Field and Pool, or Wildcat Diablo, S.A.
15. Elevation (Show whether DF, RT, GR, etc.) 3834 GR		12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug this well as follows:

1. Set CIBP over perforations (2000')
2. Back off and pull free 4 1/2" csg est. 1500"
3. Pump plugs as follows:  
25 sx on top of CIBP @ 2000"  
35 sx 50' inside 4 1/2" stub and tag  
35 sx @ 990 to cover est. top of queen @ 940'  
35 sx @ 472'-372' to cover 8 5/8" show @ 422'  
10 sx @ surface w/ D.H. marker

Location will be cleared and leveled to NMOC D Rules & Regulations.

Notify N.M.O.C.C. in sufficient time to witness

Plugging

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Phelps White</u>	TITLE <u>President</u>	<u>622-1001</u>	DATE <u>09/27/91</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>Field Rep</u>		DATE <u>10/21/91</u>

CONDITIONS OF APPROVAL, IF ANY: