

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TI
(Other instruct.
reverse side)ICATE*
on re-Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 10813

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Houston

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Wildcat11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA**23 T.14 S., R.10E.**

12. COUNTY OR PARISH

Quero

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL ☒ WELL GAS ☐ WELL OTHER ☐

2. NAME OF OPERATOR

Leland A. Hodges, Trustee

3. ADDRESS OF OPERATOR

200 Throckmorton Street, Fort Worth, Texas 761024. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface**1980' from West line and 470' from South line of Section**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5017' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Pursuant to telephone call to USGS at Artesia we propose to plug and abandon this well as follows:

1. Fill hole with mud from 3046', T.D., to 2475' with mud.
2. Set cement plug 2375' - 2475'.
3. Shoot 8 5/8" casing at approximately 1300' - 1400' and pull casing.
4. Fill hole with mud from 2375' to 1000'.
5. Set cement plug from 900' - 1000'.
6. Shoot 10 3/4" casing at approximately 750' and pull casing.
7. Pull 13 3/8" casing.
8. Fill hole with mud to surface.
9. Set 10 sack cement plug in top of surface casing.
10. Level location and set required marker.

RECEIVED

NOV 9 1970

U. S. GEOLOGICAL SURVEY
ARTESIA, OFFICE

18. I hereby certify that the foregoing is true and correct

SIGNED

Bob Donagan

TITLE

Geologist

DATE

10-27-70

(This space for State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED

R. L. BEEKMA

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.