

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

RECEIVED  
MAR 10 1979  
K-6772

<p><b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)</p>		<p>5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/></p> <p>5. State Oil &amp; Gas Lease No. K-6772</p>
<p>1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Dry</b></p>	<p>7. Unit Agreement Name</p>	
<p>2. Name of Operator <b>McClellan Oil Corporation</b> ✓</p>	<p>8. Farm or Lease Name <b>Marlisue</b></p>	
<p>3. Address of Operator <b>P.O. Box 848, Roswell, New Mexico 88201</b></p>	<p>9. Well No. <b>3</b></p>	
<p>4. Location of Well UNIT LETTER <b>C</b>, <b>1155</b> FEET FROM THE <b>North</b> LINE AND <b>1485</b> FEET FROM THE <b>West</b> LINE, SECTION <b>24</b> TOWNSHIP <b>14-S</b> RANGE <b>29-E</b> NMPM.</p>	<p>10. Field and Pool, or Wildcat <b>Undesg. Double L Queen</b></p>	
<p>15. Elevation (Show whether DF, RT, GR, etc.) <b>3790' GL</b></p>	<p>12. County <b>Chaves</b></p>	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon this test as follows :

100' plug in base of casing (1957')  
Shoot and pull 4½" casing.  
100' plug at stub of 4½" casing (depending on depth of stub)  
100' plug over base of salt (1050) if stub is below base of salt.  
100' plug in and out of 8 5/8" casing (403)  
15 sx plug at surface. Pump heavy mud between plugs.  
Install dry hole marker and restore surface to as near its original condition as possible.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Joe L. McClellan

TITLE Operator

DATE 3/17/79

APPROVED BY W. A. Gressett

TITLE SUPERVISOR, DISTRICT II

DATE MAR 20 1979

CONDITIONS OF APPROVAL, IF ANY: