

UNITED STATES  
DEPARTMENT OF THE INTERIOR

SUBMIT IN TRIPPLICATE\*  
(Other instructions on re-  
verse side)

Form approved.  
Budget Bureau No. 42-R1424.

GEOLOGICAL SURVEY N. M. O. C. C. C. O. Y

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. LC - 029419 (a)	
2. NAME OF OPERATOR Getty Oil Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR P. O. Box 730; Hobbs, New Mexico 88240		7. UNIT AGREEMENT NAME Skelly Unit	
4. LOCATION OF WELL (Report location clearly and in accordance with any state requirements. See also space 17 below.) At surface Unit E, 1980' FNL and 660 FWL		8. FARM OR LEASE NAME	
14. PERMIT NO.		9. WELL NO. 101	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3929 DF		10. FIELD AND POOL, OR WILDCAT Grayburg-Jackson	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 22-17S-31E	
		12. COUNTY OR PARISH Eddy	
		13. STATE New Mexico	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>	WATER SHUT-OFF	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	FRACTURE TREATMENT	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	SHOOTING OR ACIDIZING	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	(Other)	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	REPAIRING WELL	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
ABANDON*	<input type="checkbox"/>	ABANDONMENT*	<input type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>		

(Other) xxx - Bring cement top up

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Pull rods and tubing.
2. Run cement bond log.
3. Perforate @ top of cement.
4. Run BP below perfs.
5. Run tubing and squeeze packer.
6. Pump cement to above top of 7-Rivers 200' (7-R top @ 2013)
7. Pull tubing and packer.
8. Drill out and retrieve BP.
9. Run temperature survey.
10. Rerun tubing and rods. Place well back on production.

RECEIVED

AUG 30 1977

U. S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED David C. C. C. C.

TITLE Area Superintendent

DATE August 9, 1977

(This space for Federal or State office use)

APPROVED BY  
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

\*See Instructions on Reverse Side

ACTING DISTRICT ENGINEER