

RECEIVED

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
C. C. D. ARTESIA OFFICE

MAR - 5 1992

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different well.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Premier Production Co. ✓

3. Address and Telephone No.

P.O. Box 1246, Artesia, NM 88210, (505) 748-2093

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Section 22 NE/4 NE/4  
T-18S R-29E

Case Designation and Serial No.

NEA 0055696

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Yates Premier Fed. #4

9. API Well No.

300152436300S1

10. Field and Pool, or Exploratory Area

Turkey Track, SR, Q, GB, SA

11. County or Parish, State

Eddy, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☒ Other plug  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Propose to plug & abandon this well in the following manner: (The 4½" casing is circulated & will be left in tact.) Rig up to pull rods & tubing; go in hole w/tubing open-ended. Spot 500' cement plug (50sax) Class C 3000' to 2500'. Tag up plug at 2500'. Spot 500' (50 sax) cement plug from 2500' to 2000'; tag up plug at 2000'. Spot 50 sax 500' cement plug at 2000' to 1500'; tag up plug at 1500'. Spot 300' (30 sax) cement plug from 1100' to 800'. Isolate bottom of salt; tag up & spot 150' plug from 500' to 350'. Isolate top of salt; spot 50' surface plug. Cut off well head & install 4'X4" dry-hole marker. Back fill pits & clean up location.

14. I hereby certify that the foregoing is true and correct

Signed

*Perry Jones*

Title owner/operator

Date

2/18/92

(This space for Federal or State office use)

Approved by

*Darrell Glass*

Title

PETROLEUM ENGINEER

Date

3/2/92

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\*See Instruction on Reverse Side