

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
(Other instructions
verse side)

DATE

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO. *dsf*

NM-83580

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

RECEIVED

1. OIL WELL GAS WELL OTHER

DEC - 4 1991

2. NAME OF OPERATOR
Strata Production Company

3. ADDRESS OF OPERATOR
648 Petroleum Building, Roswell, NM 88201

O. C. D.
ARTESIA OFFICE

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

860' FWL & 2030' FSL

7. UNIT ASSIGNMENT NAME

8. FARM OR LEASE NAME

Aguila Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Winchester-Delaware

11. SEC. T., E., M., OR BLE. AND SURVEY OR AREA

Sec 4: T20S, R28E

14. PERMIT NO. API-30-015-26430

15. ELEVATIONS (Show whether DF, ST, GR, etc.)
3298' GR

12. COUNTY OR PARISH
Eddy

13. STATE
NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETION

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDISE

ABANDON*

SHOOTING OR ACIDIZING

ABANDONMENT*

REPAIR WELL

CHANGE PLANE

(Other)

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DURING PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Strata Production Company plans to plug and abandon the Aguila Federal #1 well in the following manner:

- 1) Set CIBP @ a depth of 6100' w/ 35' cement on top (cover perfs 6140'-6249')
- 2) Set 100' cement plug @ 4500'-4600'.
- 3) Set 100' cement plug @ 2800'-2900'.
- 4) Set 100' cement plug @ 700'-800' across intermediate csg. Shoe @ 767'.
- 5) Set 50' surface plug @ 50'-0'.

There will be a mud system circ between cement plugs.
No pipe to be cut-off for salvage. Wellhead to be cut off.
Anchors removed, dryhole marker set and location leveled.

18. I hereby certify that the foregoing is true and correct

SIGNED Regina Linley

TITLE Production Analyst

DATE 11/21/91

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE 11/29/91

*See Instructions on Reverse Side