

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 067968

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

9. WELL NO.

10. FIELD AND POOL, OR WILDCAT

Dollarhide Queen
11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 19-24S-38E

12. COUNTY OR PARISH 13. STATE

Lea New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☐ GAS WELL ☐ OTHER ☒ Water Injection Well

West Dollarhide Queen Sand Unit

2. NAME OF OPERATOR

Skelly Oil Company

West Dollarhide Queen Sand Unit

3. ADDRESS OF OPERATOR

P. O. Box 1351, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

330' FSL and 2310' VEL Sec. 19-24S-38E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3164' KB

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well is in an area that has not responded to waterflood operations. In order to reduce operating costs we propose to plug and abandon the well as follows:

- 1) Move in pulling unit. Pull tubing and packer.
- 2) Set 7" bridge plug at 3675'.
- 3) Circulate hole with 10.2# mud.
- 4) Spot 15 sacks cement on top of bridge plug.
- 5) Spot 100 sacks cement 1100-1560' across top of salt section. → 700-1360'
- 6) Spot 10 sack cement plug at surface.
- 7) Set marker.

All intervals not cemented will be filled with 10.2# mud.

18. I hereby certify that the foregoing is true and correct.

(SIGNED) J. R. Avent J. R. Avent

TITLE Dist. Admin. Coordinator

DATE March 4, 1973

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED
AS AMENDED
MAR 12 1973
ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side