

HOBBS OGD

NOV 07 2011

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

New Mexico Oil Conservation Division, District 1

1625 N. Hatch Drive
Hobbs, NM 88240FORM APPROVED
OMB No 1004-0137
Expires: July 31, 2010

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

5. Lease Serial No.

LC 060821 (a)

6. If Indian, Allottee or Tribe Name

SUBMIT IN TRIPLICATE - Other instructions on page 2

1. Type of Well

☒ Oil Well☐ Gas Well☐ Other

2. Name of Operator

Celero Energy II, LP

3a. Address

400 W. Illinois, Ste. 1601 Midland TX 79701

3b. Phone No. (include area code)

(432)686-1883

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FSL & 1980' FEL

(O) Sec 21, T14S, R31E

7. If Unit of CA/Agreement, Name and/or No.

8. Well Name and No.

West Cap Queen Sand Unit #25

9. API Well No.

30-005-01118

10. Field and Pool or Exploratory Area

Caprock, Queen

11. Country or Parish, State

Chaves, NM

12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans	<input type="checkbox"/> Plug and Abandon	<input checked="" type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	

13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.)

Request 1 yr temporary abandoned status Subject well is a producing well which last produced in 1971. It would have virtually no injection support & would not likely be commercial if returned to production at this time. However, the well has potential in the event that a CO2-pilot project in the Rock Queen Unit to the North is successful & subsequently expanded.

1. POOH w/ any production equipment.
2. RIH w/ bit & scraper to 2916'.
3. RIH w/ pkr & pressure test csg.
4. Set CIBP @ 2916' & cap w/ 35' of cmt.
5. Run tbg & circ well w/ FW pkr fluid.
6. POOH w/ tbg. Perform MIT.

Please Contact The BLM Roswell Field Office At Least 24 Hours Prior To The Scheduled Casing Integrity Test For Wells In Chaves And Roosevelt County. During Office Hours Or After Office Hours Call (575) 627-0205 Engineer On Call During Office Hours Phone (575) 627-0275 Or Phone (After Hours) Call (575) 626-5749

APPROVED FOR 3 MONTH PERIODENDING JAN 25 2012

14. I hereby certify that the foregoing is true and correct Name (Printed/Typed)

Lisa Hunt

Title Regulatory Analyst

Signature

Lisa Hunt

Date 10/19/2011

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

/S/ DAVID R. GLASS

Title PETROLEUM ENGINEER

Date

OCT 25 2011

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office ROSWELL FIELD OFFICE

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

NOV 09 2011

CELERO ENERGY

FIELD: Caprock
LEASE/UNIT: West Cap Queen Sand Unit
COUNTY: Chaves

DATE: Oct. 17, 2011
BY: MWM
WELL: 25
STATE: New Mexico

Location: 660' FSL & 1980' FEL, Sec 21(O), T14S, R31E

SPUD: 10/57 COMP: 10/57

CURRENT STATUS: Producer-SI

Original Well Name: Saner #1

KB =

GL = 4,276'

API = 30-005-01118

10-3/4" 32# @ 162' w/90 sx-circ'd

T-Anhy @ 1223'

T-Salt @ 1353'

B-Salt @ 2012'

T-Yates @ 2165' (Gas)

T-Queen @ 2956'

Calc'd TOC @2451', enlargement = 10%; yld = 1.26 ft3/sk

CIBP at 2916' w/35' cmt

Top of Queen @ 2956'

Perfs unknown, suspect 2956'-2973'

7", 20# @ 2980' w/100 sx

PBTD - 2980'
TD - 2981'

BUREAU OF LAND MANAGEMENT

**Roswell Field Office
2909 West Second Street
Roswell, New Mexico 88201
575-627-0272**

Temporary Abandonment of Wells on Federal Lands Conditions of Approval

A temporary abandoned well is defined as a completion that is not capable of production in paying quantities but may have value as a service well. Pursuant to 43 CFR 3162.3-4(c), no well may be temporarily abandoned for more than 30 days without the prior approval of the authorized officer.

Temporary Abandonment (TA) status approval requires a successful casing integrity test as follows:

1. A Notice of Intent (NOI) Sundry Notice (Form 3160-5) requesting approval to run a mechanical integrity test (MIT) or casing integrity test (CIT).
2. A description of the temporary abandonment procedure.
 - A. A bridge plug or packer must be installed as close to 50 feet above any open perforations or open hole as possible. If a cement plug is used, the top of the cement must be verified by tagging.
 - B. The wellbore must be filled with corrosion inhibited fluid and pressure tested to 500 psi. The casing shall be capable of holding this pressure for at least 30 minutes with a 10% allowable leakoff.
 - C. All downhole production/injection equipment (tubing, rods, etc.) shall be removed from the casing if they are not isolated by a packer.
 - D. A bradenhead test must be conducted. If the test indicates a problem exists, a remedial plan and time frame for remediation shall be submitted within ninety (90) days of the test.
 - E. Contact the BLM Roswell Field Office at least 24 hours prior to the scheduled Casing Integrity Test. For wells in Chaves and Roosevelt County, during office hours or after office hours call (575) 627-0205. Engineer on call during office hours phone (575) 627-0275 or phone (after hours) call (575) 626-5749.

Wells that successfully pass the casing integrity test may be approved for Temporary Abandonment (TA) status up to 12 months.

1. Submits a subsequent Sundry Notice (Form 3160-5) requesting TA approval.
2. Attaches a clear copy of the original pressure test chart.
3. Provided justification why the well should be temporarily abandoned rather than permanently plugged and abandoned and an estimated date that the well will be returned to beneficial use or plugged and abandoned.
4. Describes the temporary abandonment procedure.

The TA status could be extended without another casing integrity test provided there was no leak-off during the test and the test was witnessed by a BLM representative.

If the well does not pass the casing integrity test, then the operator shall within 30 days submit to BLM for approval one of the following:

1. A procedure to repair the casing so that a TA approval can be granted.
2. A procedure to plug and abandon the well.