

Submit 1 Copy To Appropriate District Office
District I - (575) 393-6161
1625 N French Dr, Hobbs, NM 88240
District II - (575) 748-1283
811 S First St, Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd, Aztec, NM 87414
District IV - (505) 476-3460
1220 S. St. Francis Dr, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised August 1, 2011

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

SUNDAY SERVICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-025-25116
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/> <i>Inj</i>		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator Occidental Permian Ltd.		6. State Oil & Gas Lease No.
3. Address of Operator HCR 1 Box 90 Denver City, TX 79323		7. Lease Name or Unit Agreement Name North Hobbs (G/SA) Unit Section 26
4. Well Location Unit Letter <u>B</u> : <u>330'</u> feet from the <u>North</u> line and <u>1900</u> feet from the <u>East</u> line Section <u>26</u> Township <u>18S</u> Range <u>37E</u> NMPM Lea County		8. Well Number 311
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3660.8 GL		9. OGRID Number: 157984
		10. Pool name or Wildcat Hobbs (G/SA)

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

OTHER: ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. TIH and tag CIBP at 4175'. Cap with 35' of cmt.
2. Circulate 10# MLF.
3. *P450* Spot 30 sx of cmt from 2855'-2955". WOC. Tag.
4. Perf and sqz 50 sx of cmt from 1790'. WOC. Tag.
5. *435* Perforate at 400'. Sqz well and circulate to surface. Top well-off as necessary.
6. Cut off wellhead and install dry hole marker with labeling.
7. Clean up location, remove anchors.

The Oil Conservation Division Must be notified
24 hours prior to the beginning of plugging operations.

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Mendy A Johnson TITLE ADMIN ASST DATE 6/15/12

Type or print name MENDY A JOHNSON E-mail address MENDY-JOHNSON@OXY.COM
For State Use Only 806-592-6280

APPROVED BY: [Signature] TITLE STATE MGR DATE 6-27-2012
Conditions of Approval (if any):

JUN 28 2012

8 5/8" @ 353'
Cmt w/ 225 sx Circulated

425'
Perf at 160' Circulate to surface

Perf at 1790' Sqz with 50 sx

Perf & SQ
30 sx of cmt from 2855-2955'

CIBP set at 4175' Capped with 35' of cmt

Perforations 4220-4284'

4 1/2" @ 4325 w/ 425 sx
TOC 2770'