Submit 1 Copy To Appropriate District Office	State of New Mexico		Form C-103	
<u>District 1</u> – (575) 393-6161	Energy, Minerals and Natural Resources		Revised August 1, 2011 WELL API NO.	7
625 N French Dr., Hobbs, NM 88240 vistrict II – (575) 748-1283 HOBBS OCD		30-025-2549 29519		
811 S First St., Artesia, NM 38210 OIL CONSERVATION DIVISION		5. Indicate Type of Lease	1	
District III – (505) 334-6178 1000 Rio Brazos Rd , Aztec, NH 87412 2012 Santa Fe NM 87505		STATE FEE	_	
1220 S St Francis Dr , Santa Fe, NM		6. State Oil & Gas Lease No.		
SUNDAY NOTICES AND REPORTS ON WELLS		7. Lease Name or Unit Agreement Name	1	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS)			South Hobbs (G/SA) Unit	
1. Type of Well: Oil Well Gas Well Other Temporarily Abandoned			8. Well Number 206	
2. Name of Operator			9. OGRID Number: 157984	
Occidental Permian Ltd. 3. Address of Operator			10. Pool name or Wildcat Hobbs (G/SA)	1
HCR 1 Box 90 Denver City, TX 79323			100 1001 111110 01 11 11110 11 (0/011)	
4. Well Location				
Unit Letter H >>- : 1640_	feet from theNorth lir	ne and280	_feet from theEastline	
Section 6 Township 19S Range 38E NMPM Lea County				
11. Elevation (Show whether DR, RKB, RT, GR, etc.)				Ž.
36	23' KB			1000
12. Check Appr	opriate Box to Indicate N	ature of Notice,	Report or Other Data	
NOTICE OF INTENTION TO: SUBSE			SEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ REMEDIAL WOR				
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRI			ILLING OPNS. □ P AND A □	
PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMEN			T JOB	
DOWNHOLE COMMINGLE				
OTHER: OTHER:				
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date				
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.				
1 DOOLL with the and also				
1. POOH with tbg and pkr.				
2. TIH w/ bit and clean out to 4100. TOH w/ bit.				
3. RIH w/ 5 ½" CIBP and set at 4090'. Cap with 35' of cmt.				
4. Circulate 10# MLF.				
5. Spot 30 sx of cmt from 2873-2973'. WOC. Tag.				
6. Spot 50 sx of cmt from 1498-1698'. WOC. Tag.				
7. Perforate at 300'. Sqz well and circulate to surface. Top well-off as necessary.				
8. Cut off wellhead and install dry hole marker with labeling.				
9. Clean up location, remove an	chors.			
Spud Date:	Rig Release Da	ate:		
The desired of the de				_
I hereby certify that the information above is true and complete to the best of my knowledge and belief.				
Mandun Och Den Drun. 7/10/13				
SIGNATURE CONTINUE TITLE SOCIATION TO 2				
Type or print name WENDY (A. THURDNE-mail address PHONE: OXY. COM				
For State Use Only				
APPROVED BY:	TITLE &	15T. 111GP	DATE 1-11-6017	
THE OIL CONSERVATION DIVISION MU BE NOTIFIED 24 HOURS PRIOR TO THE	JST		- 2010	

BEGINNING OF PLUGGING PERATIONS

JUL 167, 2012

