

New Mexico Oil Conservation Division, District 1
1625 N. French Drive
Hobbs, NM 88240

Form 3160-3
(August 1979)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS
Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

FORM APPROVED
OIL AND GAS
Expires November 30, 2000

SUBMIT IN TRIPLICATE - Other instructions on reverse side

1. Type of Well
☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator
MARKS and OWNER PRODUCTION

3. Address
P.O. BOX 1087 HOBBS NM 88240

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
**6601 F₂L 6601 F₂L
NEM 22 24S 32E**

5. Phone No. (include area code)
505-393-9358

5. Lease Serial No.
NMLC062267A

6. If Indian, Allottee or Tribe Name

7. If Unit or CAA Agreement, Name and/or No.

8. Well Name and No.
Brady Fed #3

9. API Well No.
3062508156

10. Field and Pool, or Exploratory Area
DOUBLE X Delaware

11. County or Parish, State
LEA COUNTY, NM

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
☐ Notice of Intent	☐ Acidize	☐ Deepen	☐ Production (Start/Resume)	☐ Water Shut-Off
☐ Subsequent Report	☐ Alter Casing	☐ Fracture Treat	☐ Reclamation	☐ Well Integrity
☐ Final Abandonment Notice	☐ Casing Repair	☐ Plug and Abandon	☐ Recombine	☐ Other
	☐ Change Plans	☐ Plug Back	☐ Temporarily Abandon	
	☐ Convert to Injection		☐ Water Disposal	

13. Describe proposed or completed operations briefly, including estimated starting date of any proposed work and approximate duration thereof. If the nature of the work is such that it is not possible to describe the work in brief, give substance, location and measured and true vertical depths of all pertinent workings and casing. Also, if the nature of the work is such that it is not possible to describe the work in brief, give substance, location and measured and true vertical depths of all pertinent workings and casing. If the nature of the work is such that it is not possible to describe the work in brief, give substance, location and measured and true vertical depths of all pertinent workings and casing. If the nature of the work is such that it is not possible to describe the work in brief, give substance, location and measured and true vertical depths of all pertinent workings and casing.

Set CIBP @ 4875 with ^{35'} cement on top of Plug
Perforate @ 2400' & Squeeze &
Set 100' cement @ 2300-2400'
Cut + Pull 2000' 4 1/2 casing
Set 50' in + out of 4 1/2 casing stub
Set 100' @ ^{Top} of Salt F/360-1460'
Set 50' in + out of 8 5/8 shoe @ 353' F/300-400'

Set 50' Plug @ Surface
Instal Marker, & clean
location



Quinton Welborn
Quinton Welborn

CONTROLLER
7-28-05

ORIG. SGD. DAVID R. GLAN

PETROLEUM ENGINEER

AUG 02 2005

GWW

SEE ATTACHED FOR
CONDITIONS OF APPROVAL