Submit 1 Copy To Appropriate MGS S OCD State of New Mexico Office	Form C-103
<u>District I</u> Energy, Minerals and Natural Resources	October 13, 2009 WELL API NO. 30-025-27582
1625 N. French Dr., Hobbs, NM 88240 3 2013 District II 1301 W. Grand Ave., Artesia, NM 88210 District III	
1220 South St. Trailers Dt.	5. Indicate Type of Lease STATE FEE FEE
District IV 1220 S. St. Francis Dr., Santa Fe, NM 87505	6. State Oil & Gas Lease No. V-70
SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	STATE 6
PROPOSALS.) 1. Type of Well: Oil Well Gas Well Other	8. Well Number I
2. Name of Operator NOVY OIL & GAS, INC.	9. OGRID Number 162499
3. Address of Operator 125 N. MARKET #1230 WICHITA, KS 67202	10. Pool name or Wildcat VADA PENN
4. Well Location	
Unit Letter G: 2080 feet from the NORTH line and 1986 Section 6 Township 10S Range 34E	Ofeet from the EASTline NMPM County LEA
11. Elevation (Show whether DR, RKB, RT, GR, etc.)	
4260 = GL $4275 = RKB$	
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK ☑ PLUG AND ABANDON ☒ REMEDIAL WORK ☑ ALTERING CASING ☐	
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRIF	
PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMENT	I JOB
DOWNHOLE COMMINGLE	
OTHER: OTHER: OTHER: OTHER:	1 give pertinent dates, including estimated date
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Cor	npletions: Attach wellbore diagram of
proposed completion or recompletion. 1. P.O.O.H With tubing. 35' 2. Set CIBP @6800'dump of feet cement on top. 3. Cut casing at 5500 feet spot 50 sack plug - STUB PLUG 55505450, WOC; TAG. 4. pull casing to 4283 and spot 50 sack plug - SHOE PLUG 43334233 WOC; TAG.	
2. Set CIBP @600 dump to feet cement on top. 3. Cut casing at 5500 feet spot 50 sack plug - STUB PLUG 5550 -5450 WOL FTAG.	
4. pull casing to 4283 and spot 50 sack plug - SHOE PLUG 4333-4233 WOC; TAG.	
5. pull casing to 450 feet and circulate cement to surface. 6. cut all pipe 3 feet delow groynd level and place dry hole marker.	
0 2050 - 1950	
4.B SPOT 50 SXS CMT @ 2050 - 1950.	
D RECOMMENDS USING	The Oil Conservation Division
	MUST BE NOTIFIED 24 Hours
Y NASK	or to the beginning of operations
Rig Release Date:	and softming of operations
I hereby certify that the information above is true and complete to the best of my knowledge	e and belief.
SIGNATURE MILLE ENDUS TITLE President	DATE 05/16/2013
Type or print name Michael Novy E-mail address: novyoil@aol.com PHONE: (316) 794-7200	
For State Use Only 1/2/2013	
APPROVED BY: 1 Conditions of Approval (if alw):	
Conditions of Approval (if ahy):	
\mathcal{J}	

