

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
OMB No. 1004-0135  
Expires January 31, 2004

**SUNDRY NOTICES AND REPORTS ON WELLS**

*Do not use this form for proposals to drill or re enter an abandoned well. Use Form 3160-3 (APD) for such proposals.*

**SUBMIT IN TRIPLICATE - Other instructions on reverse side**

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Yates Drilling Company

3a. Address

105 S. 4th Str., Artesia, NM 88210

3b. Phone No. (include area code)

505-748-8463

4. Location of Well (Footage, Sec., T., R., M., OR Survey Description)

330' FSL & 1880' FEL Section 34-12S-31E

5. Lease Serial No.

NM-90584

6. If Indian, Allottee or Tribe Name

7. If Unit or CA/Agreement, Name and/or No.

8. Well Name and No.

Garner Federal #4

9. API Well No.

30-005-20971

10. Field and Pool, or Exploratory Area

SE Chaves QN Gas Area Assoc

11. County or Parish, State

Chaves, NM

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans	<input checked="" type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomple horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recomple in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

See attachment.

**SEE ATTACHED FOR  
CONDITIONS OF APPROVAL**

14. I hereby certify that the foregoing is true and correct

Name (Printed/Typed)

Karen J. Leishman

Title Operations Tech

Signature

*Karen J. Leishman*

Date 3/21/2006

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

(ORIG. SGD.) ALEXIS C. SWOBODA

Title

PETROLEUM ENGINEER

Date

MAR 24 2006

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction

GW

Sundry Attachment  
3/21/2006  
Garner Federal #4  
Section 34-12S-31E  
Chaves County, NM  
30-005-20971



Current Condition of Well

2989' - 3048'

CIBP @ 2978' with cement 2953' - 2978'

2968' - 2974'

2932' - 2938'

CIBP @ 2900' with cement 2875' - 2900'

2772' - 2776'

2798' - 2802'

CIBP @ 2700' with cement 2665' - 2700'

2260' - 2270'

2282' - 2286'

CIBP @ 2200' with cement 2165' - 2200'

8 5/8" surface casing set @ 409' with cement circulated.

5 1/2" production casing set @ 3108' with cement top @ 1990'

Propose:

- 1) Set CIBP @ 2040' and spot cement from 1940' - 2040' (across top of cement)
- 2) Perforate @ 1450' (12' below top of Rustler) squeeze with 50 sxs. cement.
- 3) Perforate @ 459' (50' below surface shoe). Set retainer @ 409', squeeze with 50 sxs. cement. Spot 50' on top of retainer.
- 4) Spot plug from 0 - 100'.
- 5) Erect Dry hole marker