

Submit 1 copy to appropriate District Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
October 13, 2009

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-025-28913	✓
5. Indicate Type of Lease STATE ☒ FEE ☐	✓
6. State Oil & Gas Lease No. B-9505	
7. Lease Name or Unit Agreement Name New Mexico AT State	✓
8. Well Number 15	✓
9. OGRID Number 213190	✓
10. Pool name or Wildcat Upper Penn SANDERS; PERMO	✓
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 10,100'	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐ **HOBBS OCD**

2. Name of Operator
CrownQuest Operating, LLC

3. Address of Operator
500 W. Texas Ave., Ste 500, Midland TX, 79710

4. Well Location
Unit Letter **C** : **660** feet from the **N** line and **1980** feet from the **W** line
Section **15** Township **14-S** Range **33-E** NMPM County **Lea**

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
10,100'

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

OTHER: ☐

SUBSEQUENT

REMEDIAL WORK
COMMENCE DRILLING OPERATIONS
CASING/CEMENT JOB

OTHER: ☐

INT TO PA ☒
P&A NR ☐
P&A R ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. Spot CIBP @ 9725'. Circulate hole w/ mud laden fluid.
2. Spot 20 sx @ 9725-9575'. **CLASS H CMT WOC & TAG Pressure test csq to 500 psi.**
3. Spot 25 sx @ **8050-7050'**. WOC & Tag. **7056' (CLASS H) - DV Tool**
4. Spot 25 sx @ 4250-4150'. WOC & Tag.
5. Spot 25 sx @ 2648-2528'. WOC & Tag.
6. Spot 25 sx @ 1740-1630'. WOC & Tag.
7. Spot 25 sx @ **575-475'**. **575' to surface**
8. **10' surface plug** **CUT off wellhead. Verify cmt to surface all strings.**
9. Install Dry Hole Marker.

*** NO TAG NECESSARY IF CSG TESTS GOOD**

Spud Date:

NOTIFY OCD 24 HOURS PRIOR TO BEGINNING
PLUGGING OPERATIONS

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Ben Montgomery* TITLE Agent DATE 3/23/2016
Type or print name Ben Montgomery E-mail address: benmontgomery@hennemann.com PHONE: 432-580-7161
For State Use Only
APPROVED BY: *Mark Whitaker* TITLE Petroleum Engr. Specialist DATE 03/23/2016
Conditions of Approval (if any):

MAR 24 2016

MW

Printed: 3/7/2016

API # 3002528913

