

Submit 1 Copy To Appropriate District Office

State of New Mexico

Form C-103

Revised July 18, 2013

District I - (575) 393-6161

1625 N. French Dr., Hobbs, NM 88240

District II - (575) 748-1283

811 S. First St., Artesia, NM 88210

District III - (505) 334-6178

1000 Rio Brazos Rd., Aztec, NM 87410

District IV - (505) 476-3460

1220 S. St. Francis Dr., Santa Fe, NM 87505

Minerals and Natural Resources

OIL CONSERVATION DIVISION

1220 South St. Francis Dr.

Santa Fe, NM 87505

WELL API NO.

30-025-01342

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

312471

7. Lease Name or Unit Agreement Name

SEMU

8. Well Number

006

9. OGRID Number

298299

10. Pool name or Wildcat

MALJAMAR; GRABURG SA

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☐ Other ☒ INJ

2. Name of Operator

CROSS TIMBERS ENERGY, LLC

3. Address of Operator

400 W 7TH STREET, FORT WORTH, TX 76102

4. Well Location

Unit Letter I : 2310 feet from the S line and 430 feet from the E line

Section 32 Township 17-S Range 33-E NMPM County LEA

11. Elevation (Show whether DR, RKB, RT, GR, etc.)

4036 GL

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐

DOWNHOLE COMMINGLE ☐

CLOSED-LOOP SYSTEM ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ P AND A ☐

CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.1 5.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

MIRU est'd 2/28/2020

1. MIRU.

2. Set profile plug in packer @ 4429'.

3. Release from on/off tool and POOH w/tubing.

4. Repair wellhead.

5. RIH w/ tubing. Retrieve profile plug.

6. Pressure test TCA. Release from on/off tool and circulate packer fluid. Latch back on to on/off tool. Contact NMOCD and run MIT per representative's directive.

7. RDMO.

Spud Date:

11/10/1961

Rig Release Date:

11/30/1961

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Samanntha Avarello TITLE Regulatory Technician DATE 02/20/2020

Type or print name Samanntha Avarello E-mail address: savarello@mspartners.com PHONE: 817-334-7747

For State Use Only

APPROVED BY: [Signature] TITLE Petroleum Engineer DATE 02/23/2020

Conditions of Approval (if any):