

Submit 3 Copies To Appropriate District Office

District I

1625 N. French Dr., Hobbs, NM 88240

District II

811 South First, Artesia, NM 87210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

Form C-103

Revised March 25, 1991

WELL API NO.

30-025-26854

5. Indicate Type of Lease

STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name:

Leavelle

8. Well No.

1

9. Pool name or Wildcat

N. Shoebar Wolfcamp

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator

Gandy Corporation

3. Address of Operator

POB 827 Tatum NM 88267

4. Well Location

Unit Letter B : 660 feet from the N. line and 1980 feet from the E. line

Section 23

Township 16S

Range 35E

NMPM

County Lea

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

3984.5 RKB

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. Set CIBP 50' above perfs @ 10,122'-cap w/ 35' cement-24hrs & tag
2. Load hole w/ mud
3. Set 100' plug @ 7,537' wait 24hrs & tag
4. Set 100' plug @ 5000' wait 24hrs & tag
5. Set 100' plug in & out 5 1/2" casing stub @ 4100' wait 24hrs & tag
6. Set 100' plug @ 1600' wait 24 hrs & tag
7. Set 100' plug @ 423' wait 24hrs & tag
8. Set dry hole marker-set 10 sack surface plug

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Link EL Marks TITLE Agent

DATE 8-13-2003

Type or print name Link EL Marks

Telephone No. 505 396 5326

(This space for State use)

APPROVED BY Henry W. Wink

OC FIELD REPRESENTATIVE II/STAFF MANAGER

DATE

AUG 15 2003

Conditions of approval, if any: