

Sep 26 06 09:25a

SANDRA L. GARCIA

817-306-0171

P. 2

OCD-HOBBS

Form 3160-5
(April 2004)UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an
abandoned well. Use Form 3160-3 (APD) for such proposals.

SUBMIT IN TRIPLICATE- Other instructions on reverse side.

1. Type of Well ☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator Aspen Operating Co., LLC

3a. Address
210 W. 6th St., Suite 1301, Ft. Worth, TX 761023b. Phone No. (include area code)
817-882-9063

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1030' ENL & 2139' FWL of Sec. 5, T10S, R38E

FORM APPROVED
OMB No. 1004-0137
Expires March 31, 2007

5. Lease Serial No.

LC-063623A

6. If Indian, Allottee or Tribe Name

7. If Unit or CMA Agreement, Name and/or No.

8. Well Name and No.

Branco Farms 5 Federal No. 5

9. API Well No.

30-025-33414

10. Field and Pool, or Exploratory Area

Sawyer San Andres

11. County or Parish, State

Lea, NM

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
☒ Notice of Intent	☐ Acidize	☐ Deepen	☐ Production (Start/Resume)	☐ Water Shut-Off
☐ Subsequent Report	☐ Alter Casing	☐ Fracture Treat	☐ Reclamation	☐ Well Integrity
☐ Final Abandonment Notice	☐ Casing Repair	☐ New Construction	☐ Recomplete	☐ Other
	☐ Change Plans	☒ Plug and Abandon	☐ Temporarily Abandon	
	☐ Convert to Injection	☐ Plug Back	☐ Water Disposal	

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

1. Set CIBP at 4940' & cap with 2 hrs. cement
2. Run freepoint survey & cut casing where 100% free (estimated to be at 3640' based on stretch calculation)
3. Pull casing
4. Load hole with mud
5. Spot 50 sacks Class "C" cement plug from 450' to 350'; wait 4 hrs. & tag
6. Dig out around wellhead to below bradenhead. Cut off and remove bradenhead & casing to 4' below surface
7. Spot 10 sack Class "C" cement plug at top of remaining casing
8. Prepare and set marker as per NMOC requirements
9. Remove all associated equipment and buried pipelines and reclaim surface per BLM requirements

14. I hereby certify that the foregoing is true and correct
Name (Printed/Typed)

Title Operations Manager

Signature

Keith Weaver

Date

03/23/2006

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

APPROVED

Approved by

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Title

Office

Date

SEP 26 2006

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

WESLEY W. INGRAM
PETROLEUM ENGINEER

(Instructions on page 2)

GWW

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

**Bronco Farms 5 Federal #5
Plug and Abandon Procedure
Conditions of Approval**

1. CIBP requires 35' of cement on top.
2. Casing size – 5 ½". If casing is cut 50' below 9 5/8" shoe, a combination plug can be placed 50' into stub and 50' into 9 5/8" shoe. Tag.
3. okay
4. okay
 - a. Plug required at base of Salt.
 - b. Plug required at top of Salt.
5. okay
6. okay
7. 25 sack plug at surface.
8. okay
9. okay

*not needed
covered by 9 7/8" circ. casing
MMB*