

OCD-HOBBS

Form 3160-5
(April 2004)UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENTFORM APPROVED
OMB No. 1004-0137
Expires: March 31, 2007

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

SUBMIT IN TRIPLICATE- Other instructions on reverse side.

1. Type of Well ☒ Oil Well ☐ Gas Well ☐ Other2. Name of Operator
MARKS + GARNER3a. Address
PO BOX 10893b. Phone No. (include area code)
505-393-73584. Location of Well (Footage, Sec., T., R., M., or Survey Description)
D-23-245-325
660 FUL 8 330 FUL5. Lease Serial No.
10001 LC-062269E

6. If Indian, Allottee or Tribe Name

7. If Unit or CA/Agreement, Name and/or No.

8. Well Name and No.
ERNEST FEDERAL NO. 0019. API Well No.
30-025-0816210. Field and Pool, or Exploratory Area
DOUBLE X OILFIELD11. County or Parish, State
Lea, NM

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒
- Notice of Intent
-
- ☐
- Subsequent Report
-
- ☐
- Final Abandonment Notice

TYPE OF ACTION

- ☐
- Acidize
- ☐
- Deepen
- ☐
- Production (Start/Resume)
-
- ☐
- Alter Casing
- ☐
- Fracture Treat
- ☐
- Reclamation
-
- ☐
- Casing Repair
- ☐
- New Construction
- ☐
- Recomplete
-
- ☐
- Change Plans
- ☐
- Plug and Abandon
- ☐
- Temporarily Abandon
-
- ☐
- Convert to Injection
- ☐
- Plug Back
- ☐
- Water Disposal

2526272829
Received
Hobbs
NOV 6 2006

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleate horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleation in a new interval, a Form 3160-5 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

WIRELINE SET 4'12" C.I.B. P @
4875' + and CAP WITH 2 SACKS OF CEMENT WITH
DUMPBAGS. CIRCULAR HOLE WITH 80 BR25 SALT SOL MUD.
PERFORATE @ 2400' +, SOE PKA @ 2,135' ± PORTS HOLDING
1000#. SPOT 15 SACKS OF CEMENT, @ 2450' - 2,333 FT ±, W.O.C.
AND TAG @ 2,250 FT ±, PERFORATE @ 1100' ±, PER. @ 879' ± PRESSURE
UP ON PORTS TO 1000# SPOT 15 SACKS CEMENT @ 1,162' - 945' W.O.C. + TAG
@ 910'. PERFORATE @ 325' PERFORATE 125' PRESSURE UP ON PORTS
TO 1000# SPOT 30 SK CEMENT @ 377' - SURFACE14. I hereby certify that the foregoing is true and correct
Name (Printed/Typed)

Quinton WELBORN

Title CONTROLLER

Signature

Quinton Welborn

Date 10-27-06

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Title

Office

APPROVED

NOV 6 2006

FREDERICK WRIGHT
PETROLEUM ENGINEER

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)

GWW

SUNDRY NOTICE SPECIAL STIPULATIONS

1. Approval is granted to P/A this well with the following modifications to the program:
2. The cement cap on top of the CIBP @ 4875' should be at least 25 sack of cement, to cover the base of the Salt in addition to the top of the perfs.
3. Perf and squeeze leaving at least 25 sack of cement inside the casing @ 1420' to cover the top of the Salt.
4. Perf and squeeze leaving at least 25 sack of cement inside the casing @ 403' to cover the shoe of the surface casing. This plug can be brought all the way to the surface to eliminate a separate surface plug.
5. The plugs @ 4875' and 1420' must be tagged.
6. Install the abandonment Marker.

*** All plugs should be at least 25 sacks of cement and 100 feet**

Engineering
can be reached at 505-706-2779 for any variances that might be necessary.

F Wright 11/06/06