

Submit 3 copies to Appropriate District Office

DISTRICT I

1625 N. French Dr., Hobbs NM 88240

DISTRICT II

1301 W. Grand Avenue, Artesia NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec NM 87410

DISTRICT IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, New Mexico 87504-2088

Form C-103

Revised March 25, 1999

WELL API NO. 30-025-32255
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. VB-0134
7. Lease Name or Unit Agreement Name Kiwi AKX State
8. Well No. 9
9. Pool Name or Wildcat East Livingston Ridge Delaware

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator

Yates Petroleum Corporation

3. Address of Operator

105 South 4th Str., Artesia, NM 88210

4. Well Location

Unit Letter A : 330 feet from the North line and 330 feet from the East line

Section 16 Township 22S Range 32E NMPM County Lea

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3781' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Propose to plug and abandon well as follows:

- 1) Set CIBP @ 6909' and dump 35' cement on top. Perforate squeeze holes @ 4657'
- 2) Place 100' plug 4657-4557'. WOC and tag.
- 3) Perforate @ 1285'. Place 100' plug 1285-1185', inside and outside casing. WOC and tag.
- 4) Perforate @ 920'. Place 100' plug 920-820', inside and outside casing. WOC and tag.
- 5) Spot 10 sx plug @ surface.
- 6) Cut off wellhead, weld on plate, and install dry-hole marker.

SPOT 100' PLUG F/400'-300'

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

Thereby certify that the information above is a true and complete to the best of my knowledge and belief.

SIGNATURE Stormi Davis TITLE Regulatory Compliance Technician DATE 10/6/03

Type or print name Stormi Davis

Telephone No. 505-748-1471

(This space for State use)

APPROVED BY Larry W. Wink TITLE OC DISTRICT SUPERVISOR/GENERAL MANAGER DATE OCT 14 2003

Conditions of approval, if any: