Form 3160-5 (February 2005)

UNITED STATES DEPARTMENT OF THE INTERIOR ... BUREAU OF LAND MANAGEMENT

OCD-HOBBS

FORM APPROVED OMB NO. 1004-0137 Expires March 31, 2007

Expires March 31, 2007

5. Lease Serial No.

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals

NMI C069420
6. If Indian, Allottee or Tribe Name

abandoned well. Use Form 3160-3 (APD) for such proposals.				
SUBMIT IN TRIPLICATE - Other instructions on reverse side		7. If Unit or CA/Agreement, Name and/or No.		
1 Type of Well X Oil Well Gas Well Other 2 Name of Operator EOG Resources Inc.		8. Well Name and No. West Corbin Federa 1 26		
		9. API Well No.		
		3b. Phone No. (include area co	30-025-31064	
P.O. Box 2267 Midland, Texas 79702 4. Location of Well (Footage, Sec., T., R., M., or Survey Description)		432 686 3689	10. Field and Pool, or Exploratory Area	
		South Corbin		
1830 FSL & 2047 FWL, NESW		11.0		
Séc 8, T18S, R33E		11. County or Parish, State		
		Lea NM		
12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA				
TYPE OF SUBMISSION	TYPE OF ACTION			
X Notice of Intent	Acidize	Deepen	Production (Start/Resume) Water Shut-Off	
Subsequent Report	Alter Casing Casing Repair	Fracture Treat New Construction	Reclamation Well Integrity Recomplete Other	
	Change Plans	X Plug and Abandon	Temporarily Abandon	
Final Abandonment Notice				
	Convert to Injection	Plug Back	Water Disposal	
following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the final site is ready for final inspection.) Proposal to P&A: 1. Set CIBP @ +/- 10750' + 35' cement cap. SEE ATTACHED FUR CONDITIONS OF APPROVAL CONDITIONS OF APPROVAL				
2. Spot 60 sx cement plug from 1	0250' to 10000'.	_		
3. Spot 40 sx cement plug from 6700' to 6500'. 4. Spot 25 sx cement plug from 4800' to 4700'.				
4. Spot 25 sx cement plug from 4800' to 4700'.				
5. Spot 25 Sx centent plug from 29/3. to 28/3. Tag.				
7. Spot 25 sx cement plug from 100' to surface. 8. Cut off casing & weld on P&A marker. Clean and restore location.				
14. I hereby certify that the foregoing is true and correct Name (<i>Printed/Typed</i>)		Title	2828240	
Stan Wagner		Regulatory	Apalvet	
Signature Handle De			Date 9/04/07 APPROVED	
THIS SPACE FOR FEDERAL OR STATE OFFICE U.S.				
THIS SPACE FOR FEDERAL OR STATE OFFICE USE				
Approved by		Title	SEP Date	
Conditions of approval, if any, are attached. Approval of certify that the applicant holds legal or equitable title to the which would entitle the applicant to conduct operations the	this notice does not warr those rights in the subject	ant or Office	SET DATE SET DATE OF DERICK WRIGHT FOERIUM ENGINEER	

Title 18 U.S.C. Section 1001, and Title 43 U.S.C. Section 1212, makes it a crime for any person knowingly and willfully to make to any department or agency of the United

States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

SUNDRY NOTICE SPECIAL STIPULATIONS

- 1. Approval is granted to plug this well with the following modifications to the proposed plugging procedure.
- 2. BLM records indicate that a CIBP was set @ 8520' with 35' of cement on top of it. If this is the case you can proceed from your step 3 with the plugging procedure.

All plugs below the surface plug must be at least 25 sacks of cement and 100' plus an additional 10% for each 1000 feet of depth.

Plugging procedures must conform to 43 CFR 3162.6.d and Onshore Order No. 2.III.G or NMOCD orders if they are more stringent.

ALL OF THE WORK AUTHORIZED HERE MUST BE COMPLETED WITHIN 90 DAYS.

Engineering can be reached at 505-706-2779 for any variances that might be necessary.

F Wright 9/10/07