HOBBS OCU MAY 0 4 2011

State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103

FILE IN TRIPLICATE OIL CONSERVATION DIV	Revised 5-27-2004
DISTRICT I 1220 South St. Francis Dr.	WELL API NO.
1625 N. French Dr., Hobbs, NM 88240 Santa Fe, NM 87505	30-025-28305
DISTRICT II	5. Indicate Type of Lease STATE X FEE
1301 W. Grand Ave, Artesia, NM 88210	STATE X FEE 6. State Oil & Gas Lease No.
DISTRICT III 1000 Rio Brazos Rd, Aztec, NM 87410	o. State on & das Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK	TO A South Hobbs (G/SA) Unit
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (Form C-101) for such propo	sals.)
1. Type of Well:	8. Well No. COOP 2
Oil Well Gas Well Other Injector	9. OGRID No. 157984
2. Name of Operator Occidental Permian Ltd.	9. OOKID No. 137984
3. Address of Operator	10. Pool name or Wildcat Hobbs (G/SA)
HCR 1 Box 90 Denver City, TX 79323	
4. Well Location	
Unit Letter D : 645 Feet From The North 45.	Feet From The West Line
Section 4 Township 19-S Rang	e 38-E NMPM Lea County
11. Elevation (Show whether DF, RKB, RT GR, etc.)	
3620' GL	
Pit or Below-grade Tank Application or Closure	
Pit Type Depth of Ground Water Distance from nearest fresh water	r well Distance from nearest surface water
Pit Liner Thickness mil Below-Grade Tank: Volume bbls; Con	· · · · · · · · · · · · · · · · · · ·
12. Check Appropriate Box to Indicate Nature of Notice, NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WO	ORK ALTERING CASING
	PLUG & ABANDONMENT
	AND CEMENT JOB
	7.11.5 OZ.11.2(1) 005
13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give p proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram	ertinent dates, including estimated date of starting any of proposed completion or recompletion.
proposed work) one reads that it was the completions. The wester diagrams	or proposed compression or recompression
1. Kill well.	× .
 Clean out to 4300'. RIH w/CIBP set @4296' Cap w/5 foot cement. 	
4. Acid treat well w/2250 gal of 15% NEFE HCL acid.	
	·
5. Run back in hole with injection equipment.	
6. Test casing and chart for the NMOCD.	
6. Test casing and chart for the NMOCD.7. Return well to injection.	Condition of Approval: Notify OCD Hobbs
6. Test casing and chart for the NMOCD. 7. Return well to injection. Per Underground Injection Control Program Manual	Condition of Approval: Notify OCD Hobbs office 24 hours prior of running MIT Test & Chart
6. Test casing and chart for the NMOCD. 7. Return well to injection. Per Underground Injection Control Program Manual 11.6 C Packer shall be set within or less than 100	office 24 hours prior of running MIT Test & Chart
6. Test casing and chart for the NMOCD. 7. Return well to injection. Per Underground Injection Control Program Manual 11.6 C Packer shall be set within or less than 100 feet of the uppermost injection perfs or open hole.	office 24 hours prior of running MIT Test & Chart further certify that any pit or below-grade tank has been/will be
6. Test casing and chart for the NMOCD. 7. Return well to injection. Per Underground Injection Control Program Manual 11.6 C Packer shall be set within or less than 100 feet of the uppermost injection perfs or open hole. or an (attach	office 24 hours prior of running MIT Test & Chart
6. Test casing and chart for the NMOCD. 7. Return well to injection. Per Underground Injection Control Program Manual 11.6 C Packer shall be set within or less than 100 feet of the uppermost injection perfs or open hole. or an (attach plan)	further certify that any pit or below-grade tank has been/will be ed) alternative OCD-approved
6. Test casing and chart for the NMOCD. 7. Return well to injection. Per Underground Injection Control Program Manual 11.6 C Packer shall be set within or less than 100 feet of the uppermost injection perfs or open hole. or an (attach plan)	office 24 hours prior of running MIT Test & Chart further certify that any pit or below-grade tank has been/will be
6. Test casing and chart for the NMOCD. 7. Return well to injection. Per Underground Injection Control Program Manual 11.6 C Packer shall be set within or less than 100 feet of the uppermost injection perfs or open hole. or an (attach plan)	office 24 hours prior of running MIT Test & Chart further certify that any pit or below-grade tank has been/will be ed) alternative OCD-approved ministrative Associate DATE 05/02/2011
6. Test casing and chart for the NMOCD. 7. Return well to injection. Per Underground Injection Control Program Manual 11.6 C Packer shall be set within or less than 100 feet of the uppermost injection perfs or open hole. or an (attach plan TITLE Ac	office 24 hours prior of running MIT Test & Chart further certify that any pit or below-grade tank has been/will be ed) alternative OCD-approved ministrative Associate DATE 05/02/2011 00/00xy.com TELEPHONE NO 806-592-6280
6. Test casing and chart for the NMOCD. 7. Return well to injection. Per Underground Injection Control Program Manual 11.6 C Packer shall be set within or less than 100 feet of the uppermost injection perfs or open hole. or an (attach plan TITLE AC TYPE OR PRINT NAME Mendy A. Johnson E-mail address: mendy johns	office 24 hours prior of running MIT Test & Chart further certify that any pit or below-grade tank has been/will be ed) alternative OCD-approved ministrative Associate DATE 05/02/2011