

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

N. MEXICO OIL CONSERVATION COMMISSION

HOBBS OFFICE D. O. C.

APR 20 11 05 AM '69

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator American Petrofina Company of Texas 3. Address of Operator Box 1311, Big Spring, Texas 79720 4. Location of Well UNIT LETTER 0, 660 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 31 TOWNSHIP 12S RANGE 32E NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) 4365 GR	7. Unit Agreement Name 8. Farm or Lease Name North Caprock Queen Unit #1 9. Well No. 15 10. Field and Pool, or Wildcat North Caprock Queen 12. County Lea
--	---

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Approximate starting date: 5-25-69

- Spot 50 sacks cement plug at TD 3021' through 2" EUE tubing using mud laden fluid as displacing medium. Bottom of 5-1/2" casing is at 2961'.
- Cut off 5-1/2" casing at 900' and pull.
- Run tubing to 900' (or 5-1/2" casing stub) and spot 25 sack cement plug.
- Spot 25 sack cement plug at 244' (Bottom of 8-5/8" casing).
- Place 25 sack cement plug in top of 8-5/8" casing and set 4" pipe marker.

10

JCC/js

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson J. M. Denson TITLE Asst. Dist. Mgr. of Production DATE April 28, 1969

APPROVED BY [Signature] TITLE [Signature] DATE [Signature]

CONDITIONS OF APPROVAL, IF ANY: