

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Injection Well	7. Unit Agreement Name #1
2. Name of Operator Thunderbird Oil Corporation	No. Caprock Queen Unit
3. Address of Operator P. O. Box 1778, Midland, Texas 79701	8. Farm or Lease Name No. Caprock Queen
4. Location of Well UNIT LETTER <u>F</u> , <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1981</u> FEET FROM THE <u>West</u> LINE, SECTION <u>32</u> TOWNSHIP <u>12-S</u> RANGE <u>32-E</u> NMPM.	9. Well No. Tract 6, Well No. 6
	10. Field and Pool, or Wildcat Caprock Queen (Lea)
11. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

8-5/8" @ 307'  
5-1/2" @ 3006' w/600 sx.  
3-1/2" Liner @ 2854-3043'.

1. Displace hole with salt base mud. - 2500# PER 100 bbls
2. Set CIBP @ 2800'.
3. Set 35' cement plug (5 sx.) on top of CIBP.
4. Cut off & pull 5-1/2" casing @ approx. 800'.
5. Spot 35 sx. cement plug in-and-out of 5-1/2" casing stub.
6. Spot 35 sx. cement plug in-and-out of 8-5/8" surface casing stub.
7. Spot 10 sx. cement plug @ surface and erect 4-1/2" regulation dry hole marker.
8. Clean up location for NMOCC inspection and approval.

NOTIFY Commission 24 hrs Prior to setting Plug 8

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Harry F. Schram TITLE President DATE Dec. 20, 1974

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: