

COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

## NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		5. State Oil & Gas Lease No. <b>E-1565</b>
2. Name of Operator <b>Felmont Oil Corporation</b>		7. Unit Agreement Name
3. Address of Operator <b>c/o Oil Reports &amp; Gas Services, Inc., Box 763, Hobbs, NM 88240</b>		8. Farm or Lease Name <b>State F</b>
4. Location of Well UNIT LETTER <b>K</b> <b>1980</b> FEET FROM THE <b>South</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>10</b> TOWNSHIP <b>11 S</b> RANGE <b>33 E</b> NMPM.		9. Well No. <b>1</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4285</b>		10. Field and Pool, or Wildcat <b>North Bagley &amp; Penn.</b>
		12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to plug and abandon as follows:

Set bridge plug at 10,039 & cap with 35' cement  
Set bridge plug at 9348 & cap with 35' cement  
Displace hole with 9.5# mud  
Find free point of 5 1/2" casing; if above 7340 spot 100' plug @ 7340,  
if below 7340 cut & pull 5 1/2" casing to 7340 & spot 100' cement plug  
Spot 100' plug @ 5140 (top Glorieta)  
Spot 100' plug in & out of 8 5/8" casing shoe @ 4260  
Spot 100' plug across top of salt, 1800 to 1900  
10 sack plug at surface with regulation marker  
Location to be cleared and levelled.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Merna Dales TITLE Agent DATE 3/4/76

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: