

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Temporarily Abandoned		7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company		8. Farm or Lease Name S. E. Anderson
3. Address of Operator P.O. Box 1978, Roswell, New Mexico 88201		9. Well No. 1-Y
4. Location of Well UNIT LETTER J , 1980 FEET FROM THE South LINE AND 1880 FEET FROM East LINE, SECTION 30 TOWNSHIP 9-S RANGE 35-E NMPM.		10. Field and Pool, or Wildcat Jenkins-San Andres
15. Elevation (Show whether DF, RT, GR, etc.)		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was temporarily abandoned in 1963 to hold for possible secondary recovery from steam injection. Possibilities for steam injection have decreased and we now propose to plug and abandon this well as follows:

1. 30 sx neat cement in 5½" liner from 4870-4670'.
2. Shoot and pull 9-5/8" casing as deep as possible (top of cement @ 1350')
3. 30 sx neat cement half in and out of 9-5/8" stub.
4. 10 sx in top of well.

Dry hole marker will be erected and location cleared and levelled. 13-3/8" casing will remain intact. Work will start about 10/20/69.

25 10/20/69

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Original Signed D. D. Bretches	TITLE Dist. Drlg. Supervisor	DATE 9-30-69
APPROVED BY [Signature]	TITLE SUPERVISOR DISTRICT 1	DATE
CONDITIONS OF APPROVAL, IF ANY:		