

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P.O. Box 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
OG 584	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT-" (FORM C-1011 FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator Read & Stevens, Inc.		8. Farm or Lease Name Skelly State	
3. Address of Operator P.O. Box 1518, Roswell, NM 88201		9. Well No. 1	
4. Location of Well UNIT LETTER <u>H</u> <u>2130</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE. SECTION <u>10</u> TOWNSHIP <u>10S</u> RANGE <u>33E</u> NMPM		10. Field and Pool, or Wildcat <u>Unit Flying "M" San Andres</u>	
5. Elevation(Show whether DF,RT,GR,etc.) 4225' GL		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

Describe Proposed or Completed Operations(Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Set CIBP @ 4525' w/ 35'cmt on top of plug
- 2) Load hole with saltgel mud.
- 3) Spot 35sx cmt 1950'-2050'.
- 4) Perf @ 1900', squeeze w/ 50sx class "C" cmt, leaving 100' plug inside and outside casing.
- 5) Spot 10sx plug at surface w/ 4"X10" Dryhole Marker.
- 6) Clean location for inspection.

Received verbal approval 8-22-83 from Eddle Seay.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Bruce Stebbins TITLE Drilling & Production Manager DATE 8-24-83
APPROVED BY ORIGINAL SIGNED BY JERRY SEXTON TITLE DRILLING SUPERVISOR DATE AUG 26 1983
CONDITIONS OF APPROVAL