

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>

5. State Oil & Gas Lease No. K-3983
--

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Dwight A. Tipton	8. Farm or Lease Name Nine Ranch
3. Address of Operator c/o Oil REports & Gas Services, Inc., Box 755, Hobbs, NM 88241	9. Well No. 1
4. Location of Well UNIT LETTER <u>C</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>2130</u> FEET FROM THE <u>West</u> LINE, SECTION <u>22</u> TOWNSHIP <u>10S</u> RANGE <u>33E</u> N.M.P.M.	10. Field and Pool, or Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 4201 GL	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to finish plugging as follows:

Load hole with mud.
Run freepoint on 5 1/2" casing, cut & pull from freepoint
Run tubing & spot 100' plug across 5 1/2" casing stub
Spot 100" plug across 8 5/8" casing shoe at 3940
Run freepoint on 8 5/8" casing, cut & pull from freepoint
Spot 100' plug across 8 5/8" casing stub
Spot 100' plug across 12 3/4" casing shoe at 360
Tag all plugs
Set 10 sx cement plug at surface with marker
Clean & level location.

COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PLUGGING OPERATIONS FOR THE WELL.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Donna D. Hall TITLE Agent DATE 6-2-87

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE JUN 8 1987

CONDITIONS OF APPROVAL, IF ANY: