

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

HOODS OFFICE O. G. C.  
NEW MEXICO OIL CONSERVATION COMMISSION  
JUL 21 11 50 AM '67

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
5. State Oil & Gas Lease No. OG 1319	
7. Unit Agreement Name	
8. Farm or Lease Name State of <del>New Mexico</del> "D"	
9. Well No. 1	
10. Field and Pool, or Wildcat <b>UNDESIGNATED</b>	
15. Elevation (Show whether DF, RT, GR, etc.) 4244 KB	
12. County Lea	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>Drilling Well</u>
2. Name of Operator <u>Southern Natural Gas Company</u>
3. Address of Operator <u>P. O. Box 1513, Houston, Texas 77001</u>
4. Location of Well UNIT LETTER <u>B</u> , <u>510</u> FEET FROM THE <u>North</u> LINE AND <u>2,110</u> FEET FROM THE <u>East</u> LINE, SECTION <u>11</u> TOWNSHIP <u>11-S</u> RANGE <u>33-E</u> NMPM.

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
		OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Verbal permission to P & A granted by Mr. E. F. Engbrecht July 16, 1967. We plan to spot the following cement plugs:

- 25 sack plug @ Total Depth
- 25 sack plug @ Top Wolfcamp
- 25 sack plug @ Top lb.
- 25 sack plug @ Top Tubb
- 25 sack plug @ Top Ghorietta
- 25 sack plug in and out of 8-5/8" casing set @ 3,865'
- 25 sack plug in 8-5/8" stub. In event the 8-5/8" casing is shot off below the salt, a
- 25 sack plug at base of salt