

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
--	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Coastal States Gas Producing Company		Locker
3. Address of Operator		9. Well No.
P. O. Box 235, Midland, Texas 79701		1
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>H</u> <u>1980</u> FEET FROM THE <u>N</u> LINE AND <u>660</u> FEET FROM		Crossroads (Slaughter)
THE <u>E</u> LINE, SECTION <u>25</u> TOWNSHIP <u>9S</u> RANGE <u>35E</u> NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
4093 DF		Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well is presently completed in the San Andres formation and is no longer economical to produce. The well is to be plugged and abandoned as follows:

1. Set CIBP @ 4800' w/10' cmt on top.
2. Cut 4-1/2" csg.
3. 35 sx plug @ stub.
4. 35 sx plug @ top of salt (2150') if exposed.
5. 50 sx plug in and out of 8-5/8" shoe (404').
6. 10 sx plug in top.
7. Install DHM.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Joe R. Howard TITLE Division Production Manager DATE 2-10-71

APPROVED BY Joe R. Howard TITLE SUPERVISOR DISTRICT DATE FEB 12 1971

CONDITIONS OF APPROVAL, IF ANY: