

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input checked="" type="checkbox"/> WELL GAS <input type="checkbox"/> WELL OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Midwest Oil Corporation		8. Farm or Lease Name Howard Cook
3. Address of Operator 1500 Wilco Bldg., Midland, TX 79701		9. Well No. #1
4. Location of Well UNIT LETTER 0, 660 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 31 TOWNSHIP 9-S RANGE 34-E NMPM.		10. Field and Pool, or Wildcat Vada Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4224.4 GL		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐

OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

History:

11 3/4" Set @ 335 w/ 350 Sx Cmt. (Circulated).
8 5/8" Set @ 4059 w/ 450 Sx Cmt.
5 1/2" Set @ 9834 w/300 Sx Cmt.
Perforated 9784-9798

Propose to Plug & Abandon As follows:

Set CIBP@ 9750' & w/ 35 sx cement on plug in 5 1/2" casing
Pull & recover csg. from appx. 5000'
Set 100' cmt plug in & out of stub.
Set 100' cmt plug @ base of Intermediate casing.
Set 100' cmt plug in & out of intermediate stub.
Set 100' cmt plug @ base of surface casing.
Set 10 sx cmt @ surface & install dry hole marker.
100' cmt plugs will be set above Wolfcamp Abo. & Glorietta Sections if casing is recovered through sections.
Mud will be used to set plugs.
The Commission will be notified 24 hours prior to setting cement plugs.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Gene Wilford TITLE Agent DATE 11-9-73

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: