

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State Fee
5. State Oil & Gas Lease No.
OG 2392

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name -----
2. Name of Operator Coquina Oil Corporation	8. Farm or Lease Name State 36
3. Address of Operator 418 Building of the Southwest, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER <u>N</u> <u>1980</u> FEET FROM THE <u>West</u> LINE AND <u>660</u> FEET FROM THE <u>South</u> LINE, SECTION <u>36</u> TOWNSHIP <u>10-S</u> RANGE <u>33-E</u> N.M.P.M.	10. Field and Pool, or Wildcat Inbe Permo Penn
15. Elevation (Show whether DF, RT, GR, etc.) GL 4206, KB 4218	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REVEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to P&A well as follows:

- Well Conditions: 13 3/8 @ 370'
8 5/8 @ 3964'
5 1/2 @ 9955'
TD 9960'

2. Proposed P&A Procedure:

- Set CI BP (with 30' cmt on top) at 9000'.
- Cut and pull 5 1/2 csg.
- Spot 25 sx cmt on top of 5 1/2" stub.
- Spot 25 sx cmt at top of Glorietta (5430').
- Spot 30 sx cmt in and out of base of 8 5/8" (at 3964')
- Cut and pull 8 5/8" casing.
- Spot 25 sx cmt on top of 8 5/8" stub.
- Spot 30 sx cmt in bottom of 13 3/8" csg (at 370').
- Spot 10 sx cmt in top 13 3/8"
- Fill hole between plugs with mud and erect DHM. Clean & level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J.A. Taylor TITLE Superintendent DATE 9-28-71

APPROVED BY [Signature] TITLE SUPERVISOR DISTRICT I DATE SEP 30 1971

CONDITIONS OF APPROVAL, IF ANY

RECEIVED

SEP 2 1971

OIL CONSERVATION COMM.
HOUSTON, TEXAS