

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Sun Oil Company		8. Farm or Lease Name N.M. "AWA" State
3. Address of Operator P. O. Box 1861 Midland, Texas 79701		9. Well No. 1
4. Location of Well UNIT LETTER <u>I</u> <u>660</u> FEET FROM THE <u>East</u> LINE AND <u>1980</u> FEET FROM THE <u>South</u> LINE, SECTION <u>20</u> TOWNSHIP <u>10 S</u> RANGE <u>34 E</u> NMPM.		10. Field and Pool, or Wildcat Vada Penn (Bough C)
15. Elevation (Show whether DF, RT, GR, etc.) 4234 KB		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>
REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>	
ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plugging operations to begin approximately 7-5-71 as follows:

1. Pull tubing and packer. Load hole with 9.5# brine.
2. Spot 25 sk plug 9825-10000.
3. Shoot and pull 5 1/2" casing from 5400'.
4. Spot plugs: 25 sk in & out of 5 1/2" csg. stub, 50 sk at 4150, 5 sk at surface.
5. Set marker and clear location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Bert Hughes</u>	TITLE <u>Proration Clerk</u>	DATE <u>6-9-71</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SUPERVISOR DISTRICT I</u>	DATE <u>JUN 11 1971</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

JUN 11 1971

OIL CONSERVATION BOARD
13122, 14, 15