

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

HOBBS OFFICE O. C. C.
NEW MEXICO OIL CONSERVATION COMMISSION

MAY 8 11 12 AM '69

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name Katy 684 Ltd.
9. Well No. 1
10. Field and Pool, or Wildcat Vada-Penn Ext.
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator BTA Oil Producers
3. Address of Operator 104 South Pecos, Midland, Texas 79701
4. Location of Well UNIT LETTER <u>B</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>5</u> TOWNSHIP <u>9-S</u> RANGE <u>35-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4212' G.L.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

5-6-69: Plugging Procedure:

Set Bridge plug @ 9700' or spot 25 sx
Cut 5½" csg. and set 25 sx @ stub
Set 25 sx @ 5436' (Glorieta)
Set 25 sx @ 8-5/8" shoe (4020')
Set 25 sx @ 8-5/8" stub.
Set 25 sx @ 12-3/4" shoe (385')
Set 10 sx @ surface
Put in Dry Hole marker per NMOCC Regulations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Carl E. Vigney</u>	TITLE <u>Production Supt.</u>	DATE <u>5-6-69</u>
APPROVED BY <u>John W. Stoney</u>	TITLE <u>General Manager</u>	DATE <u>5-6-69</u>
CONDITIONS OF APPROVAL, IF ANY:		