

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>K-3274</b>

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>Sun Oil Company DX Division</b>	8. Farm or Lease Name <b>N.M. II State</b>
3. Address of Operator <b>P. O. Box 1416 Roswell, New Mexico 88201</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>K</b> , <b>1980</b> FEET FROM THE <b>South</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>21</b> TOWNSHIP <b>10 - S</b> RANGE <b>34 - E</b> NMPM.	10. Field and Pool, or Wildcat <b>Vada Penn</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4220 KB</b>	12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- MIRU
- Set 25 sack plug across perforations (9654 - 9966).
- Run free point survey and shoot off 5½" OD casing and pull.
- Set 25 sack plug in and out of 5½" casing stub.
- Set 25 sack plug across top of Abo if casing stub is below top of Abo (7825).
- Set 25 sack plug across top of Glorieta (5513).
- Set 25 sack plug in and out 8 5/8" casing at 4092.
- Set 10 sack plug at surface and set dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <b>F. D. Lebo</b>	TITLE <b>District Engineer</b>	DATE <b>2-3-70</b>
APPROVED BY <b>[Signature]</b>	TITLE <b>FOR DISTRICT</b>	DATE <b>2-3-70</b>
CONDITIONS OF APPROVAL, IF ANY:		