

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name	
2. Name of Operator <b>Skelly Oil Company</b>		8. Farm or Lease Name <b>Vada Pruitt</b>	
3. Address of Operator <b>P. O. Box 1351, Midland, Texas 79701</b>		9. Well No. <b>1</b>	
4. Location of Well UNIT LETTER <b>M</b> , <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>15</b> TOWNSHIP <b>9S</b> RANGE <b>34E</b> NMPM.		10. Field and Pool, or Wildcat <b>Vada-Pennsylvanian</b>	
15. Elevation (Show whether DF, RT, GR, etc.) <b>4255' DF</b>		12. County <b>Lea</b>	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Move in workover rig. Pull rods and tubing.
- 2) Set cast iron bridge plug at 9750' and spot 35' cement on top.
- 3) Set cement plug at approximately 7500-7600'.
- 4) Set cement plug at 5350-5450'.
- 5) Set cement plug at 3950-4050'.
- 6) Set cement plug at approximately 2150-2350'.
- 7) Set cement plug from 50' to surface.
- 8) Set dry hole marker.

**Note:** All intervals not cemented will be filled with 10# mud. The 13-3/8" OD casing set at 382', the 8-5/8" OD casing set at 4000' and the 4-1/2" OD casing set at 9835' will be left in the hole.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

(SIGNED) LELAND FRANZ

SIGNED Leland Franz

TITLE District Production Mgr.

DATE Sept. 18, 1975

APPROVED BY \_\_\_\_\_

TITLE \_\_\_\_\_

DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: