

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator Midwest Oil Corporation		8. Farm or Lease Name D. V. Cook	
3. Address of Operator 1500 Wilco Building Midland, TX 79701		9. Well No. #2	
4. Location of Well UNIT LETTER B 660 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 31 TOWNSHIP 9-S RANGE 34-E NMPM.		10. Field and Pool, or Wildcat Vada (Penn)	
15. Elevation (Show whether DF, RT, GR, etc.) 4277 GR 4296 KB		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

History: Ran 11 3/4" to 336' & Cmt'd w/ 325 Sx and circulated.
Ran 8 5/8" to 4020' & Cmt'd. w/ 450 sx cement.
Ran 5 1/2" to 9864' & Cmt'd. w/ 650 sx cement.
Perforated @ 9792'-9806'.

Propose to Plug & Abandon As follows

Set CIBP@ 9750' & w/ 35 sx cement on plug in 5 1/2" casing
Pull & recover csg. from appx 5000'.

Set 100' cmt plug in & out of stub.

Set 100' cmt plug @ Base of Intermediate csg.

Set 100' cmt plug in & out of intermediate stub.

Set 100' cmt plug @ base of surface casing.

Set 10 sx cmt @ surface & install dry hole marker.

100' cmt plugs will be set above Wolfcamp Abo. & Glorietta Sections if casing is recovered through Sections.

Mud will be used to set Plugs.

The Commission will be notified 24 hrs prior to setting cement plugs.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Gene Melford TITLE Agent DATE 11-9-73

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: