

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. OG 4632
7. Unit Agreement Name
8. Farm or Lease Name MGF State
9. Well No. 1
10. Field and Pool, or Wildcat Vada (Penn)
12. County Lea

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator MONSANTO COMPANY
3. Address of Operator 101 North Marienfeld, Midland, Texas 79701
4. Location of Well UNIT LETTER <u>E</u> , 1980 FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>30</u> TOWNSHIP <u>10S</u> RANGE <u>34E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4226' RKB

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This oil well is depleted; request is made to plug and abandon as follows:

Set C.I. Bridge plug at 9900' above perforations 9934-42' w/ 35' cement plug on top.  
Displace hole w/ 10.5# mud.  
Shoot off 5 1/2" casing above top cement and pull. Set 100' plug in stub.  
Set 100' cement plug at base 8 5/8" casing at 3972'.  
Shoot off 8 5/8" casing above top cement and pull. Set 100' cement plug in stub.  
Set 100' cement plug at base 11 3/4" casing at 410'.  
Set 10 Sx plug in 11 3/4" casing at surface w/ 4" pipe marker at surface.

→ Spot 100' plugs across top of Abu & Alorietz formations if not behind pipe.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. W. Wood

TITLE District Production Manager

DATE 4/18/72

Orig. Signed by  
John Runyan  
Geologist

APPROVED BY \_\_\_\_\_

TITLE \_\_\_\_\_

DATE APR 20 1972

CONDITIONS OF APPROVAL, IF ANY: