

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-8835

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name -
2. Name of Operator TEXACO Inc.	8. Farm or Lease Name New Mexico "CQ" State
3. Address of Operator P. O. Box 728, Hobbs, New Mexico 88240	9. Well No. 3
4. Location of Well UNIT LETTER 0 , 760 FEET FROM THE South LINE AND 2080 FEET FROM THE East LINE, SECTION 35 TOWNSHIP 10-S RANGE 33-E NMPM.	10. Field and Pool, or Wildcat Inbe Permo Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4211' DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TEXACO Inc. proposes to plug and abandon subject well as follows:

1. Pull production equipment.
2. Mud up well bore.
3. Spot 40 sx plug across pay zone and up 30' above top perf.
4. Cut off and recover 4-1/2" casing from 5000'.
5. Cut off 7-5/8" casing at free pt.
6. Spot 30 sx plugs across all stubs.
7. Spot 10 sx plug at surface.
8. Install 4" Dry Hole Marker extending 4' above ground level.
9. Clean location. Plug and abandon.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Assistant District Superintendent DATE 4-22-71

APPROVED BY [Signature] TITLE SUPERVISOR DISTRICT 1 DATE APR 26 1971

CONDITIONS OF APPROVAL, IF ANY:

2 1/2" casing 13 1/4' L.

RECEIVED

APR 20 1971

OIL CONSERVATION
HOME