

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2086
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-77

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPLY OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator Texaco Inc.		8. Farm or Lease Name F. B. Gist
3. Address of Operator PO Box 723, Hobbs, New Mexico 88240		9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>31</u> TOWNSHIP <u>11S</u> RANGE <u>33E</u> N.M.P.M.		10. Field and Pool, or Wildcat Penn North Bailey Permo
11. Elevation (Show whether DF, RT, GR, etc.) 4314' DF		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Temporary Abandon</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

RECLASSIFY FROM SI-OIL TO ASD (ABANDONED, SALVAGE DEFERRED) STATUS

- 1) MIRU pulling unit. Pull rods and pump. Install BOP. Pull tubing.
- 2) By wireline, RIH with gauge ring and junk basket to \pm 9050'. POH. Set CIBP in 4 1/2" casing at \pm 9025'. Using dump bailer, cap CIBP with 35' of cement.
- 3) RIH with tubing. Load hole with inhibited water. Test casing to 300 psi. POH. Rig down pulling unit.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

397-3571

SIGNED Ja Hea TITLE Hobbs Area Superintendent DATE 5/3/83

Orig. Signed by
Paul Kautz
Geologist

APPROVED BY _____ TITLE _____ DATE MAY 10 1988

CONDITIONS OF APPROVAL, IF ANY: