

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions
verse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use APPLICATION FOR PERMIT for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐
2. NAME OF OPERATOR
BTA Oil Producers
3. ADDRESS OF OPERATOR
104 So. Pecan, Midland, Texas 79701
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface
660' FNL & 660' FEL, Sec. 10, T-9-S, R-35-E

5. LEASE DESIGNATION AND SERIAL NO.

NM-071549

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Cities 688 Ltd.

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Middle Allison Penn Ext.

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 10, T-9-S, R-35-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4173' X.B.

12. COUNTY OR PARISH

13. STATE

Lea

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other) **Cementing & Tests**

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

6-28-69: Spudded in 1 p.m. 6-28-69. Drilled 17' hole to 400'. Ran 12-3/4" O.D. 33.38# surface casing set @ 400' w/275 sx Class B w/2% c.c. Plug down 10:30 p.m. 6-28-69. WOC.

6-29-69: After WOC 18 hrs., pressure tested casing to 600 psi - Held O.K. Now drilling ahead.

7-3-69: Drilled 11" hole to 4060'. Ran 8-5/8" O.D. 24,28 & 32# J-55 & N-80 casing set @ 4060' w/400 sx cement. Plug down 9 a.m. 7-3-69. WOC.

7-4-69: After WOC 18 hrs., pressure tested casing to 1000 psi - Held O.K. Now drilling ahead.

7-5-69: Now drilling 7-7/8" hole @ 4562'.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE **Engineer**

DATE **July 9, 1969**

(This space for Federal or State office use)

APPROVED

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

JUL 11 1969

*See Instructions on Reverse Side

J. L. GORDON
ACTING DISTRICT ENGINEER

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.